



## Auspicious T2 - Emergency stop

Panel mounted emergency stop, for mounting in Ø22mm hole. Activated and held when pushed, and released by turning the head.









Panel mounted emergency stop, for mounting in Ø22mm hole. Activated and held when pushed, and released by turning the head. A complete emergency stop consists of the following parts:

- Switch
- Coupling
- Contact-block (1-2 pcs.)

There are also some accessory parts:

- Emergency stop label
- Cover to prevent unintended activation

## Coupling

The coupling is simple pushed on to the bottom of the switch. The coupling is easy to take of again, by pushing the yellow parts, and pulling the coupling from the switch. This makes it easy to connect and replace.

## Contact-blocks

There is space for 2 contact blocks on a coupling. These are simply places in the coupling where they fasten. They are easy to remove again. The contact-blocks are activated when the switch is pushed down.

- NO contact block (green) connects the two screw-terminals when activated
- NC contact block (red) diconnects the two screw-terminals when activated



www.matronics.eu/519015



**Push-Kontakt, Twist-release** SKU 519015



**Accessory, Contact block (NO)** SKU 519500



**Accessory, Shield** SKU 519533



Accessory, Coupling (required) SKU 519510



Accessory, Contact block (NC) SKU 519501



**Accessory, Emergency stop sign** SKU 519534

## Product pictures





