

## LED DRL and indicator adapter, 12V-24V

Simple controller that turns off the DRL when the indicator is activated. Used when the indicator are built in to the DRL.



Simple controller that turns off the DRL when the indicator is activated. Used when the indicator are built in to the DRL.

They are sold individually, so if you want right and left you need to purchase 2.

There is 19cm wires in both ends, and the controller itself is 11cm and 2.5cm in diameter.

### Connection

It is important to connect the controller the right way, it is marked which end goes to the lamp and vice versa. The connection of wires can be seen below:

- Red = DRL
- Brown = position light
- Yellow = indicator
- White = ground

Buy online at:

[www.matronics.eu/24608510](http://www.matronics.eu/24608510)



**LED DRL and indicator adapter, 12V-24V**

SKU 24608510

Product pictures

