

Case Optum LED DRL conversion kit +2020 (LED forlygte)

Complete set with two light sources allowing you to change the color of the driving light on your Case Optum



Complete set with two light sources allowing you to change the color of the driving light on your Case Optum. These light sources provide a powerful light equivalent to the original.

By default, the light sources are dual color with yellow and white, but can be customized in other colors upon request.

Connection

Color change occurs by swapping the two wires, plus and minus. You can choose to have the light sources glow constantly yellow, or you can purchase a Dual color color changer. With the Dual Color Multicontrol, they can also flash as warning lights.

Installation

The heatsink on the back of the lamp is removed.

Remove the long light guide by unscrewing two screws.

Remove the light source, secured by one screw. The two soldered wires should be cut or desoldered.

Loosen the wire in the gland and feed it further into the lamp. Strip the insulation off the wire so the provided Wago connectors can be attached.

Apply thermal paste and screw the light source in place.

Connect the light source to the Wagos. Test to ensure you get the correct color, as you may need to swap the wires.

Install the light guide and reassemble the lamp.

Buy online at:

www.matronics.eu/400200-AMCW

Specifications

LEDs 12 x 5W LEDs (12 x 1W effective)

Voltage 12V



Yellow / Cold white 6000K

SKU 400200-AMCW

Product pictures

